



SW version >= 1.1.30.0	Short Instructions	14.04.2015
------------------------	--------------------	------------

Installation overview

1 Double click *setup.exe*



2 Follow installation steps



PC Requirements

OS: Windows 7 or higher

CPU: 1GHz or faster 32-bit (x86) or 64-bit (x64) processor

RAM: 1GB RAM if using Windows 32bit or 2GB RAM if using Windows 64bit

DISK: At least 200MB of free space


USB stick: USB stick for data transfer, at least 200MB, standard Windows format (FAT32)

You need to have Administrator permissions for install process. If you don't have, ask company administrator to install it.


SW version >= 1.1.30.0	Short Instructions	14.04.2015
------------------------	--------------------	------------

Übersicht Installation

1 Starten Sie per
Doppelklick *setup.exe*



2 Folgen Sie den
Installations-Schritten



PC-Anforderungen

OS: Windows 7 oder höher

CPU: 1GHz oder schneller 32-bit (x86) oder 64-bit (x64) Prozessor

RAM: 1GB RAM für Windows 32bit oder 2GB RAM für Windows 64bit

DISK: Mindestens 200MB freier Speicherplatz

USB stick: USB-Stick für Datentransfer, $\geq 200\text{MB}$, Standard Windowsformatierung (FAT32)

Für die Installation werden Administrator-Rechte benötigt. Bei Bedarf wenden Sie sich bitte an Ihre IT-Administration.